



The Friberg Spray Head/Spreader



The spreader (right) is recommended at lower water pressures, where the spreader plate can be manually adjusted for a good washer spread.

3 spray heads:

- For 1" connection.
- For 1¼" connection.
- For 1½" connection.

2 spreaders:

- For ½" connection.
- For 1½" connection.

This washer spray head is intended to be fitted through a hole in the lid of the pan to be cleaned, or which contains the items to be washed.

The top of the spray head contains a threaded connector (1", 1½" or 1¼" as standard, other sizes made to order) for connection of a circulation pump. The pressure of the water rotates the distributor and produces a powerful current.

The shape of the spray head blades can easily be adjusted to produce the required distribution pattern in the container.

Guarantee: 1-year guarantee

The product is CE-labelled

Rights to alter specifications reserved.



Fribergs Verkstäder AB • Håkantorps, SE-53496 VARA, SWEDEN
Phone: +46 512-300040 • Fax: +46 512-60100 • info@fribergs.se • www.fribergs.se